



# EVAC Evacuation hood

---



The EVAC evacuation hood is a simple and reliable life saver for rescue operations. It can be used together with any SCBA having an extra air connection.

The hood is placed over the head of the person to be rescued and then the hose is connected to the extra air connection of the SCBA. A constant air flow is then supplied into the hood. Due to the unique design with an inflatable collar no further action is needed after placing the hood over the head. When connected the collar will inflate automatically and seal the hood around the neck.

- Designed without inner mask makes it easy to put on
- Inflatable neck collar gives automatic sealing
- Large transparent visor with good field of vision
- Delivered with bag suitable to attach on the SCBA

The hose length is 1.1 meter.

## Technical specification

Air flow : 60 l/min

Dimensions : 200 x 180 x 90 (bag)

Weight : 0.7 kg

# Accept cookies from this site

---

This website uses cookies to to improve your experience on the site. By clicking accept, you agree to our [privacy\\_policy](#) and [cookie\\_policy](#).

- Do not accept cookies
- Only accept functional cookies
- Accept all cookies