



# Spirocom GRA

---

This product is not available for sale in the  
US or Canada.



Spirocom GRA (Generic Radio Adapter) is a radio adapter that can be connected to most well-known long range radios on the market. The Spirocom system is built to handle the difficult conditions at a fire scene and still deliver high quality sound.

The short cable is equipped with a connector that connects to the contact of the long range radio. A robust fastening clip is available as an accessory to secure the adapter to a carrying pocket.

The buttons and display is used to set the group number. Group setting is made in advance and remembered by the unit, on the way to an incident the only required action is to start the system. During use the adapter has a safety lock to eliminate the risk of activating the buttons by mistake when the radio is carried in a pocket.

On the top of the unit there is a connection for auxiliary equipment, such as external PTT or lapel speaker/microphone.

- Display showing group number setting
- Buttons to switch between group numbers
- Contact for connection of accessories
- Powered with 3 AAA batteries
- Battery level indication and low battery indication
- Variant with Ex/UL classification

## Technical specification

Approval : EU - CE approved

Standard : EU - EX II 1 G Ex ia IIC T4 (some models)

Frequency EU : 868 Mhz

Battery type (2) : 3 x AAA

# Accept cookies from this site

---

This website uses cookies to to improve your experience on the site. By clicking accept, you agree to our [privacy\\_policy](#) and [cookie\\_policy](#).

- Do not accept cookies
- Only accept functional cookies
- Accept all cookies