

SERVICE AND TESTING SCHEDULE

This schedule is valid for DIVING breathing apparatuses (SCUBA).

The schedule shows minimum requirements for service and testing as recommended by Interspiro.

Local requirements may differ due to regulations and environmental conditions.

In case of doubt consult your local Interspiro representative.

# APPARATUS / COMPONENT	Preventive Maintenance				
	BEFORE USE	AFTER USE	EVERY YEAR	EVERY 6 th YEAR	EVERY 8 th YEAR
1 Breathing Apparatus, complete	U	C I U	I II T		
2 Pressure Regulator & Warning Device				R II	
a. Cylinder connection			R		
b. Anti freezing caps			R		
c. Medium pressure hoses	I		I II+III		
d. DP1 Surface supply hoses			I II		R
3 Full Face Mask & Breathing Valve		D I I	R	R	
4 Harness / BC	U	I	I		
5 Cylinder / Cylinder Pack		I	I		
a. Cylinder			Periodic inspection in accordance with national regulations.		
b. Cylinder valve, service parts			Service is advised to be performed in the same periodic interval as cylinders, however it must be done at least every 6 years.		

U = Short user test

C = Cleaning

I = Inspection

D = Disinfection

T = Performance test on calibrated test equipment

R = Renew service parts according to Service Manual

I If necessary.

II Environmental conditions and frequency of use must be considered. Frequent use and/or use in aggressive environments may lead to shorter inspection/maintenance intervals.

III Medium pressure hoses older than 15 years (from date of manufacture) shall not be used.



Keeps You Breathing