



Product news



Service advice



Safety advice



### Upgraded visors

We have upgraded our firefighting masks with an extra robust visor that is approved according to the US product standard for breathing apparatus, "NFPA". The new visor does not only meet all the requirements of the European standards EN136:1998 Cl.3 + and EN 137:2006 type 2, but also the tougher heat requirements in NFPA:2019. The new visor is slightly thicker in the middle part to withstand tests at elevated temperatures regarding exposure to heat radiation.



#facemasks

### Part numbers and ordering

- All complete masks keep the current part number.
- Spare part visor 460190350 (basic version - standard in the Spiromatic mask), keeps the current part number.
- Spare part visor 460190351 (hard coated = extra scratch resistance), keeps the current part number.
- The spare part visor 96701-51 (hard coated & anti-fog treated - standard in masks S and Inspire, changes part number to 460200200. During a transition period orders can be placed on both of these part numbers.



### Replacement of batteries

"Duracell MN2400" has been discontinued from the manufacturer and is replaced by "Procell PC2400". Our products are now supplied with this new battery type.



The current battery spare part numbers are replaced with:

Procell PC2400 10-pack	98814-53
Procell PC2400 100-pack	98814-54

#spiroguide

#spirocom



### New piston with integrated diffuser

We have upgraded the piston (460190386) with an integrated diffuser. Now the diffuser is an integral part of the piston and not added as an extra part. The change will not affect the use of the equipment.



#plug-in regulators