

## Spirolite pack 323.4

---



## Product description

The Interspiro cylinder pack has a total volume of 6.8 L with an unlimited service life, "NLL" — Non-Limited Life. The cylinder pack consist of two cylinders mounted together with a pipe protected inside the handle and is equipped with one cylinder valve. The design with two smaller cylinders has the following advantages:

- Lower profile makes it possible to enter narrow passages
- Better seating position in fire truck
- Center of gravity closer to the body
- Possibe to move more freely, for example lying on your back when spraying water at the roof
- Easier to drag out a fire fighter in an emergency
- Easier handling between mission since it can not roll and is easy to place upright
- Cylinder valve protected by carrying handle

The cylinder valve has a pressure gauge, burst disc and safety ratchet to prevent uninteional closing.

The cylinder pack can be equipped with an optional Cylinder Quick Coupling.

## Technical specification

✓Approval : 2014/68/EU

✓Approval (2) : UN

✓Standard : EN12245

✓Standard (2) : ISO11119-3

✓Material : Thermoplatsic liner

✓Material (2) : Carbon/Glass fibre with Epoxy resin

✓Connection : M17 x 1,5 neck thread

✓Working pressure : 300 bar

✓Test pressure : 450 bar

✓Breathing gas : Breathing air (EN12021)

✓Length : 678 mm

✓Width : 265 mm

✓Thickness : 118 mm