



# Divator Steel pack 326

---



The low profile of the Divator steel pack configuration allows the diver to work with less water resistance in fast-flowing currents. With the cylinder valve facing downward there are no valves or hoses behind the diver's head, greatly reducing snagging hazards. The valve down configuration allows the diver to reach the valve and all hoses even when wearing a restricting dry suit. The handle makes it is to carry the cylinder pack and also acts as protection for the regulator.

- Low profile gives safer access to confined spaces
- Low profile minimizes resistance in current waters
- Excellent balance for the diver
- Quick connection interface to harness or BC/BCW
- Convenient carrying handle
- Regulator position simplifies cylinder valve handling

## Technical specification

Approval : 2014/68/EU (Pressure Equipment Directive)

Standard : ISO 9809-2

Material : Steel - CrMo

Connection : M18 x 1.5 neck thread

Service life : Unlimited

Working pressure : 300 bar

Test pressure : 450 bar

Breathing gas : Breathing air (EN10012)

Volume : 12.0 L (2 x 6.0 L)

Length : 636 mm

Width : 331 mm

Thickness : 147 mm

Weight : 21.0 kg (empty)

# Accept cookies from this site

---

This website uses cookies to to improve your experience on the site. By clicking accept, you agree to our [privacy\\_policy](#) and [cookie\\_policy](#).

- Do not accept cookies
- Only accept functional cookies
- Accept all cookies