



# DOT SuperLight - HP

---



The Carbon Fibre SuperLight cylinder is a lightweight fully wrapped composite type cylinder.

The cylinder valve includes a pressure gauge indicating cylinder pressure at all times. It has an upstream connected disc safety relief valve. The hand wheel is diamond shaped for easier handling when wearing gloves and to prevent accidental closure of the valve.

It is available in variants with 30, 45 or 60 minute duration.

This cylinder fits high pressure versions (4500 psi) of the SCBA models "Incurve S9", "Interspiro S9", "Incurve USA", "QS II USA and "Spiromatic 90USA".

The cylinder can be equipped with an optional cylinder quick coupling.

## Technical specification

Approval : DOT-SP 10915/TC

Service life : 15 years

Working pressure : 4500 psi

Test pressure : 7500 psi

# Accept cookies from this site

---

This website uses cookies to to improve your experience on the site. By clicking accept, you agree to our [privacy\\_policy](#) and [cookie\\_policy](#).

- Do not accept cookies
- Only accept functional cookies
- Accept all cookies