



# Firefighting helmet F300

---



The F300 is a next generation high-performance helmet for firefighting, rescue operations, traffic accidents and similar missions. It is also approved for shipboard firefighting.

It is made from a specially developed high temperature resistant thermoset material and offers the largest possible freedom of movement with its innovative helmet shape and low weight. With the individually adjustable inner lining, it can simply be adapted to fit individual head sizes and shapes using the dial-fit feature.

The 3-point chin strap made from Nomex has a quick release and is individually adjustable both in height and width. To further ensure a perfect fit and optimal comfort the wearing height can also be adjusted.

The luminescent white color together with all around reflective labels ensure high visibility in the most difficult environments.

Accessories are added to the helmet using the Multi Function Adapter (MFA) which easy and quickly can mount a range of different, such as:

- Torches
- Visors
- Metal visors
- Ear protection

The helmet fulfills the optional additional requirements in EN443 regarding contact with liquid chemicals, electrical insulation capacity E2/E3 and usage at low temperatures down to -40 C.

## Technical specification

Approval : PPE 2016/425

Approval (2) : Solas

Material : Outer shell - Heat resistant thermoset

Material (2) : Inner shell - Heat resistant polyurethane

Standard : EN 443

Weight : 0.9 kg / 1.0 kg (M/L)

# Accept cookies from this site

---

This website uses cookies to to improve your experience on the site. By clicking accept, you agree to our [privacy\\_policy](#) and [cookie\\_policy](#).

- Do not accept cookies
- Only accept functional cookies
- Accept all cookies